

## **ELECTROMECHANICAL POWER STEERING FITTING INSTRUCTIONS**

- Fitting the steering on the auxiliary chassis of the vehicle
- Connect all the wiring using the corresponding connectors, insert the key or card into its box.
- Connect the VDO plug of the VDO diagnostic system to the vehicle and turn it on.
- Once the parallel has been made, parametrise the steering by following and entering the data corresponding to the vehicle.
- After completing the installation and parametrisation, check that the diagnostic machine shows no errors for the steering system.
- Fitting the steering on the auxiliary chassis of the vehicle
- Connect all the wiring using the corresponding connectors, insert the key or card into its box.
- Connect the VDO plug of the VDO diagnostic system to the vehicle and turn it on.
- Once the parallel has been made, parametrise the steering by following and entering the data corresponding to the vehicle.
- After completing the installation and parametrisation, check that the diagnostic machine shows no errors for the steering system.